



QUESTION & ANSWER

HIGHER QUALITY, BETTER SERVICE

Provide One Year Free Update!

<https://www.passquestion.com>

Exam: **DES-1121**

Title: Specialist - Implementation
Engineer PowerMax and
VMAX Family Solutions
Version 1.0

Version: DEMO

1.In Unisphere which role has limited privileges that can only view the information about a storage array and is unable to make any configuration changes?

- A. None
- B. Monitor
- C. StorageAdmin
- D. Auditor

Answer: B

2.Which product(s) support(s) only 7+1 in RAID 5 configurations?

- A. VMAX3
- B. VMAX All Flash and PowerMax 8000
- C. VMAX All Flash and PowerMax 2000
- D. VMAX All Flash

Answer: D

3.A systems administrator plans to use Non-Disruptive Migration (NDM) to migrate data from a VMAX array running Enginuity 5876 to a PowerMax running PowerMaxOS 5978.

Which NDM mode will be used?

- A. Metro-based
- B. Adaptive Copy
- C. Asynchronous
- D. Pass-through

Answer: B

Explanation:

<https://www.delltechnologies.com/asset/en-us/products/storage/technical-support/h17133-non-disruptive-migration-best-practices-and-operational-guide.pdf>

4.What does a service level define*?

- A. Expected average throughput for a Storage Group
- B. Expected average response time target for a Storage Group
- C. Expected average response time target for a disk group
- D. Expected average throughput for a disk group

Answer: B

5.Where are the Host I/Os directed to when the Storage Group is in a Non-Disruptive Migration CutoverReady state?

- A. Source array only
- B. Held in host cache
- C. Source and target arrays
- D. Target array only

Answer: D